

OAKS16 LCD Board コネクタ端子表

C N 1

ピン番号	信号名	接続先
1	P 97	NC
2	P 96	NC
3	P 95	NC
4	P 94/DA1	NC
5	P 93/DA0	NC
6	P 92	NC
7	P 91	NC
8	P 90	NC
9	BYTE	NC
10	P 87	NC
11	P 86	NC
12	RESET	NC
13	P 85/MN1	NC
14	P 84/INT2	NC
15	P 83/INT1	SW10
16	P 82/INT0	SW9
17	P 81	NC
18	P 80	NC
19	P 77	LED8
20	P 76	LED7
21	P 75	LED6
22	P 74	LED5
23	P 73	LED4
24	P 72	LED3
25	P 71	LED2
26	P 70	LED1
27	P 67/TXD1	NC
28	P 66/RXD1	NC
29	P 65	NC
30	P 64	NC
31	P 63/TXD0	NC
32	P 62/RXD0	NC
33	P 61	NC
34	P 60	NC
35	NC	
36	NC	
37	GND	GND
38	GND	GND
39	5V	IC3 OUT
40	5V	5V

C N 3

ピン番号	信号名	接続先
1	P 57	NC
2	P 56	NC
3	P 55	NC
4	P 54	NC
5	P 53	NC
6	P 52	NC
7	P 51	NC
8	P 50	NC
9	P 47	NC
10	P 46	LCD1 RS
11	P 45	LCD1 R/W
12	P 44	LCD1 E
13	P 43	LCD1 DB7
14	P 42	LCD1 DB6
15	P 41	LCD1 DB5
16	P 40	LCD1 DB4
17	P 37	SW8
18	P 36	SW7
19	P 35	SW6
20	P 34	SW5
21	P 33	SW4
22	P 32	SW3
23	P 31	SW2
24	P 30	SW1
25	P 27	NC
26	P 26	NC
27	P 25	NC
28	P 24	NC
29	P 23	NC
30	P 22	NC
31	P 21	NC
32	P 20	NC
33	P 17	NC
34	P 16	NC
35	P 15	NC
36	P 14	NC
37	P 13	NC
38	P 12	NC
39	P 11	NC
40	P 10	NC